

Important notes before installing:

1. All installation work should be done by a qualified professional to avoid damage to this product.
2. This gauge dash pod may discolour or warp if exposed to direct sunlight for long periods. To avoid this, SAAS recommends using a sun shade to protect the dash pod and gauges from extreme heat.

FITTING STEPS

Note: Fits all models excluding: VZ Berlina, VZ Calais, VZ Adventra.



1. Carefully remove the original cover by prying it open with a flat object (screwdriver or similar). Clips are at the front.



2. Remove the clips from underneath the original cover so they can be attached to the new gauge pod.



3. Position clips around the gauge pod ready to mount back in place of the original panel.



4. While open, proceed to wire the gauges before placing the new gauge pod into position.



5. Gently and evenly push the new gauge pod into position ensuring clips lock into place.