



# TOYOTA HILUX Gauge Dash Pod

## Installation Instructions

Part No: SGP1105

v20190627

### Important notes before installing:

- All installation work should be done by a qualified professional to avoid damage to this product.
- This product is supplied raw with a brushed surface finish and may discolour if exposed to direct sunlight for long periods. To avoid this, SAAS recommends colour matching this product to suit your vehicles interior. (See below for painting tips)


### Fitting Steps:

- Fit the gauge cups to the dash pod. (See below for cup assembly)
- Place the bottom mounting base in the centre of your dash. (See below for correct positioning)
- Mark out the 2 screw holes and the 2 larger holes for your gauge wiring to pass through.
- Drill out the 2 larger holes first and use the supplied self drilling screws to screw in the mounting base. **Do not over tighten screws.**
- Place the dash pod over the mounting plate and push it down evenly to lock it in. To remove the dash pod, just pull it up from one corner **slowly** until the self locking fasteners let go.


### Painting Tips:

- For best painting results, use a scotch pad to lightly scuff the surface, then clean with a wax and grease remover before applying a plastic primer and then your colour.


### Gauge Cup Assembly:



**Note:** Insert screws until gauge cup is firm. **DO NOT OVER TIGHTEN SCREWS.**




### Dash Pod Mounting Position:



## Installing Gauges to Cups:

- The supplied o-rings (one for each gauge) are used to fit gauges to cups. The placement of the o-ring will determine how tight the gauge will sit in the cup. (refer to diagram)



## Warranty Terms & Conditions:

SAAS Automotive Pty Ltd warrants this product against defects in factory workmanship and materials for a period of twelve (12) months from the date of original purchase. This warranty applies to the first retail purchaser, is non-transferable and covers only where the product has been subjected to normal use or service. Provision of this warranty shall not apply to any SAAS Automotive product that has been used for a purpose for which it is not designed, or which has been altered in any way that would be detrimental to the performance or life of the product, or misapplication, misuse, negligence or accident. Warranty claims to the manufacturer must be transportation prepaid and accompanied with dated proof of purchase. On any part or product found to be defective after examination by SAAS Automotive Pty Ltd, SAAS Automotive Pty Ltd will only repair or replace the merchandise through the original selling dealer or on a direct basis. SAAS Automotive Pty Ltd assumes no responsibility for diagnosis, removal and/or installation labour, loss of vehicle use, loss of time, inconvenience or any other consequential expenses. The warranties herein are in lieu of any other expressed or implied warranties, including any implied warranty of suitability, and any other obligation on the part of SAAS Automotive Pty Ltd, or the selling dealer.

**For further assistance email: [tech@saasautomotive.com.au](mailto:tech@saasautomotive.com.au)**



SAAS Automotive PTY LTD  
25 Metrolink Circuit West, Campbellfield,  
Victoria 3061 Australia

ABN: 48166279670  
ACN: 166279670

Phone: +61 3 9930 0100  
Fax: +61 3 8339 2270  
Email: [tech@saasautomotive.com.au](mailto:tech@saasautomotive.com.au)  
Web: [www.shopsaas.com](http://www.shopsaas.com)